
T771/U
Technical Document File
Procedures for Mounting The Pision Na. CYZZ-TD0001L 2/2

- 1. Decrease the supply pressure to 0MPa (check there is no residual pressure) so that the cylinder can be operated manually.
- 2. If the cylinder cannot be operated at full stroke due to external stroke restriction (external stopper, adjuster bolt, etc.), release the stopper, etc. and make the cylinder able to operate at full stroke.
- 3. If the piston is disengaged, it can be confirmed that the external slider end is in contact with the head cover or plate at the B side or they are separated largely at the A side (i.e. difference in a gap between both ends).



Note) The slider type figure shows the CY1S (slide bushing type).

(Take the same procedures for mounting the disenageged piston for the CY1L)